M1 Submersible	Maintananaa Taak	Maintenance Frequency			
Pump Checklist	Maintenance Task	Daily	Weekly	Monthly	Annually
Pump Use/sequencing	Prior to commencing maintenance, test run check for correct operation and excessive noise, heat and vibration. Confirm operation of all emergency stops & trips.  Turn off/sequence unnecessary pumps.	X			
Overall Visual Inspection	Complete everall viewal inerportion to be			Х	
Level Control	Check level electrodes, transducers and float switches. Wash down.	/	X		
Check Lubrication	Ensure that all bearings are lubricated per the manufacturer's recommendation.			X	
Check Packing	Check packing for wear & repack as necessary. Consider replacing packing with mechanical seals.	7		X	
Motor/Pump Alignment	Aligning the pump/motor coupling allows for efficient torque transfer to the pump.		7		X
Check Mountings	Check & secure all pump mountings.			Х	
Pump Inspection	Lift pumps and check the pump and motor for painting and corrosion and apply painting if required.				х
Check Bearings	Inspection bearings and drive belt for wear. Adjust, repair or replace as necessary.				X
Hydraulic end	Check impellers wear rings, vanes for corrosion and fixing.				X
Motor Condition	Checking the condition of the motor through temperature or vibration analysis.				х
Hydraulic Performance	Test the hydraulic characteristics and performance curves.				X
Vibration Checking for dry installation	Checking the Vibration for motor/pump using vibration meter		X		